RECEIVER, RS232C(FEMALE)

PC, RS232C(FEMALE)

1. Use only three Line(TX,RX, GND)

2. SET TX line must be connected with PC RX.

   (Pin number 3 with number 2)

3. SET RX line must be connected with PC TX.

   (Pin number 2 with number 3)

4. Connector is famale type

Title	{Title}	
Size A	Document Number {Doc}	Rev {RevCode}
Date: Thursday, November 13, 2003	Sheet 1 of 1	